


Change the picture size on your new television




Press the "PIC SIZE" button on your new television's remote control.



Your television is likely on the 4:3 setting.



Press the “PIC SIZE” button on the remote control until “FULL” is highlighted in blue.



Now your television’s picture size should appear to be larger. Wait for the Picture Size menu to disappear. You’re done!